


Using the Memory Stick PRO Duo™ Media

To load the PLATO Achieve Now Memory Stick PRO Duo™ into the PSP® system:


- Open the cover to the memory stick slot.
- Making sure the power is off, insert the Memory Stick PRO Duo™ card into the slot with the writing face up.
- Press until fully inserted.
- Replace the memory stick slot cover.




Starting an Adventure

To begin a PLATO Achieve Now Adventure:

1. Turn on the PSP® system via the **Power/Hold switch**.
2. Use the **right/left arrows (directional buttons)** to scroll through the main menu XMB™ (XrossMediaBar) to the **Game** icon.
3. Use the **up/down arrows (directional buttons)** to scroll to the **Memory Stick™** icon.
4. Click **X** to select.
5. Scroll up/down through the PLATO Achieve Now on PSP menu to locate the desired Adventure. (*Adventures are listed in alphabetical order and contain a prefix for easy communication with young students.*)
6. Click **X** to select an Adventure.



HINT: To completely exit an Adventure and return to the main menu, select the **Home button** at the lower-left corner of the device.



Warning!

Do not update—PSP® system software/firmware.